



October 13, 2022

Discovery and Tracking of a Novel Sulfolane-Degrading Bacterium through Laboratory and Field Studies

Linda Eastcott, Arujala Thavendrarasa (Imperial Oil Limited)

Philip Dennis, Ximena Druar, Melody Vachon, Jennifer Webb, and Sandra Dworatzek (SiREM)

Eva McLean, Sylvain Hains, and Andrew Madison (Golder Associates)

Trent A. Key (ExxonMobil Environmental and Property Solutions Company)

E&PS

Agenda

Background Remedial Activities Microbiology & Molecular Biological Tools Conclusions



Background

Sulfolane – Background

- Industrial solvent used as a sweetening agent in sour gas processes in the upstream
- Historically used from the 1960s to the 1980s
- Cyclic ether similar to 1,4-dioxane
- C₄H₈SO₂

Biodegradation Pathways:



Conceptual Site Model – Geology **3D GEOLOGICAL MODEL**







Lithology



Conceptual Site Model – Sulfolane Distribution





2010 2008 5732000 5732000 5731500 5731500-5731000-5731000-5730500 5730500-5730000-5730000-5729500-5729500-5729000 5729000-5728500 5728500-5728000 572800 672000 672500 673000 673500 674000 674500 675000 675500 672000 672500 673000 673500 674000 674500 675000 6755



2012 5732000 5731500-5731000-5730500-5730000-5729500-5729000-5728500 5728000





672000 672500 673000 673500 674000 674500 675000 675500



SiREM

E&PS

672000 672500 673000 673500 674000 674500 675000 675500

Remedial Activities

Mobile Unit System Design BIOSPARGING







Biosparging and Monitoring Well Network



Biosparging Wells

- 12m Interval 3 wells
- 17m Interval 3 wells

Monitoring Network

- 7m Interval 8 wells
- 12m Interval 14 wells
- 17m Interval 14 wells

Biosparging and Monitoring Well Network (Cont.)





Groundwater Monitoring Program



- Sulfolane
- Geochemistry
 - Electron acceptors (e.g., dissolved oxygen), nutrients, and biodegradation by-products
- Microbiology & Molecular Biological Tools



Sulfolane Concentrations – 17m Interval





Dissolved Oxygen Concentrations – 17m Interval





Microbiology & Molecular Biological Tools

Application of Microbiology & Molecular Biological Tools BIOSPARGING RESULTS

- Provide supporting evidence that *in situ* biodegradation occurred due to biostimulation with oxygen
- Multiple lines of evidence approach was needed to showcase sulfolane biodegradation was a result of biosparging
 - □ Sulfolane media plate counts
 - Microcosm treatability study
 - **Quantitative** (q)PCR
 - Microbial Community Analysis (NGS)



Site Groundwater - Total Bacteria via qPCR (16S rRNA)





Groundwater - Sulfolane Degrading Bacteria Plate Counts



Biodegradation of Sulfolane – Colony Identification







Bioprospecting Overview

- Stage 1: Treatability study to assess biodegradation capacity of sulfolane from natural microorganisms present at site
- Stage 2: Enrichment culture study to select for sulfolane-degrading microorganisms ("weed out" organisms not of interest)
- Stage 3: DNA sequencing (NGS) of microbial community to aid in the identification of sulfolane-degrading microorganisms
- Stage 4: Isolation and pure culture study to confirm if isolated microorganisms biodegraded sulfolane and performed DNA sequencing on colonies to identify.
- Stage 5: qPCR method development (biomarker) to directly measure sulfolane-degrading microorganism in site samples







Stage 1: Treatability Study

- Microcosm bench study completed under aerobic conditions
- Sulphate release quantified as a surrogate for aerobic sulfolane degradation
- Controls set up and sterilized with mercuric chloride and sodium azide
- Groundwater inoculum collected from a well located downgradient to the biosparging injection zone
- Treatment microcosms were sampled on Days 2, 5, 9, 12 and 14

E&PS

 $C_4H_8O_2S + 6.5O_2 \rightarrow 4CO_2 + 3H_2O + 2H^+ + SO_4^{2-}$ (Greene et al., 2000)



Stage 2: Enrichment Culture Study

- Treatability study was completed again enrich for sulfolane degraders
- Sulfolane was the only organic carbon source in these incubations
- Repeated sulfolane decrease from 50-60 ppm down to non-detect in 2-4 weeks in aerobic culture inoculated from biosparge area







Stages 3-5: Biomarker Development

- Created enrichment cultures in media containing sulfolane as the only organic carbon source
- Reduced total microbial community diversity down to 14 organisms with 2 putative taxa identified as potential sulfolane degraders based on increased relative abundance when incubated with sulfolane
 - Comamonadaceae: Family contains several previously described sulfolane degraders (Acidovorax, Variovorax, Rhodoferax spp.). Isolate unable to degrade sulfolane
 - Rhodococcus: Species contains previously described to desulfinate other cyclic organosulfur compounds (dibenzoethiophene sulfone). Confirmed to be sulfolanedegrading isolate
- qPCR assay and associated primers designed to target Rhodococcus isolate





MBT Method Development & Validation

- MBT (qPCR) method was developed for a sulfolane-degrading Rhodoccocus sp. present at the site and ground-truthing was completed against 10 site samples
 - 5 time-series samples in one well within the biosparging area
 - 5 samples across various wells
- qPCR method was applied to 10 site samples
 - 5 time-series samples in one well within the biosparging area

ORP (mV)

-147.7

-65.3

-90.2

Suflolane Suflolane Degrader

(cells/L)

5E+05

1E+06

2E+04

2E+04

4E+04

Biosparging off

(mg/L)

< 0.0010

2 6 3.8

< 0.0010

5 samples down the plume length

Well ID

HP-52-38

HP-104-43

HP-46-13

Upgradient

Source Area





DO (mg/L)

0.24

2.75

0.19

Conclusions & Future Efforts

Conclusions & Future Efforts

Conclusions

- Biosparging successfully demonstrated for sulfolane remediation
- An increased understanding of site microbiology has increased our understanding of the potential for intrinsic sulfolane biodegradation at the site
- Molecular Biological Tools (e.g., qPCR) can improve conceptual site models, performance monitoring, and optimization of remediation technologies

Future Efforts

- Analyze additional field-samples with developed qPCR assay for sulfolane-degrader to gauge assay robustness for field-scale monitoring [in progress]
- Sequence genome of *Rhodococcus* isolate [in progress]
- Complete treatability study and track organism growth during sulfolane degradation to gauge potential use of qPCR data for rate estimation



Thank you! Questions or Comments?

Linda Eastcott: linda.j.eastcott@esso.ca Phil Dennis: pdennis@siremlab.com



