
#### Vertex Environmental Inc.



#### In-Situ Remediation of Petroleum Hydrocarbons – Combining Remedial Techniques

Remediation Technologies Symposium 2013 Banff, Alberta October 17, 2013 Bruce Tunnicliffe

## Overview



- Background
  - Vertex
  - Remediation Technologies
- Case Studies
  - Commercial Redevelopment
  - Residential Oil Spill
  - Flowing Sands
- Conclusions
- Questions



# Background

- Bruce Tunnicliffe, P.Eng., M.A.Sc.
- Vertex = Environmental contracting
- Remediation & injection services:
  - High-Resolution Characterization
  - Remedial Design
  - Bench, pilot, and full-scale
  - ISCO, ISCR, enhanced biodegradation
  - Treatment systems work (MPE, SVE, etc)







# **Remediation Technologies**

- Excavation
- Systems Technologies
  - Pump and Treat, Multi-Phase Extraction, Soil Vapour Extraction
- In-Situ Chemical Oxidation
  - Fenton's Reagent, Permanganate, Persulphate, Percarbonate
- In-Situ Chemical Reduction
  - Zero Valent Iron (ZVI), edible oils, lactates
- Enhanced Bioremediation
- Risk Assessment



### Excavation







## Case Study #1





Former Car Dealership




- Residential redevelopment proposed
  - Formerly used for automotive servicing, gasoline service station, painting and automotive repair
  - Record of Site Condition (RSC) required
- PHC impacts identified in the soil and groundwater (to 8 m bgs):

Contaminant	Max Soil Impact (ug/g)	Soil Std (ug/g)	Max GW Impact (ug/L)	GW Std (ug/L)	
Benzene	-	0.17	880	5	
PHC (F1)	1,300	65	2,800	750	
PHC (F2)	1,800	150	30,000	150	
PHC (F3)	-	1300	6,500	500	2
MtBE	-	1.4	60	15	

#### **Proposed Remedial Approach:**

- 1) Demolish existing building
- 2) Excavate impacted soil except property boundary wedge
- 3) Dewater the excavation, treat & discharge
- 4) Install horizontal wells to treat gw & the wedge
- 5) ISCO for remaining PHCs in gw & in soil in the wedge
- 6) Confirmatory sampling






#### 1) Demolish existing building






#### 2) Excavate impacted soil except property boundary wedge



#### 3) Dewater the excavation, treat and discharge



#### 4) Install horizontal infrastructure within the open excavation



#### 5) ISCO for remaining GW impacts and wedge area soil impacts



#### Summary:

- Work completed between Sept 2012 and Jan 2013
- 3 excavations completed
- 2,600,000 L of PHC impacted groundwater treated
- 28 horizontal wells installed in large excavation
- 2 ISCO injection rounds completed
  - into temporary injection points within the wedge
  - into horizontal wells
  - Approx. 8,000 kg: persulphate and base activation
  - Approx. 65,000 L of solution




#### **Results:**

- After excavation, soil impacts removed, except in wedge
- After excavation, PHC groundwater impacts remained (10,000 ug/L)
- After 1 injection, PHC groundwater and soil impacts, but greatly diminished (<1,000 ug/L)</li>
- After 2 injections:
  - All soil samples in the wedge met the Standards (>95% treatment)
  - All groundwater samples met the Standards (>99.5% treatment)
- A third injection round was planned, but was not required
- Successful clean-up



# Case Study #2






- 150 year old stone farm house with fuel oil AST
- Fuel line between AST and furnace leaked
- Oil entered basement floor drain
- Migrated through weeping tiles and to the subsurface







#### **Conditions:**

- Free phase PHC(F2) oil on concrete floor
- MW installed floating free phase oil
- Soil: boulders, cobbles, sand till over sandy silt till
- Soil underlain by fractured limestone bedrock
- Water table at 2.2 m below basement floor
- GW 1,000,000,000 ug/L PHCs
- Soil >10,000 ug/g PHCs

Remedial Approach:

- Excavation with underpinning
- Possible ISCO







#### Conditions (after excavation):

- Hand digging required around footings
- Bedrock outcrops in excavation
- Significant remaining PHC impacts
- Free phase oil at base of excavation

Parameter	Max Soil Impact (µg/g)	Soil Std (µg/g)	GW from Sump (μg/L)	GW Std (µg/L)
PHC (F1)	250	55	4,400	750
PHC (F2)	3,100	98	770,000	150
PHC (F3)	1,000	300	260,000	500







- Five ISCO injections into HWs
- Total:
  - 14,000 L of 15% to 20% base-activated persulphate


**Results:** 

Parameter	GW Std (µg/L)	Groundwater (µg/L)				
		Pre-ISCO	Post Inj #2	Post Inj #4	Post Inj #5	
F1 PHC	750	4,400	<100	<100	<100	
F2 PHC	150	770,000	61,000	860	<100	
F3 PHC	500	260,000	39,000	240	<100	
Total	-	1,034,400	100,000	1,100	<100	

- Greater than 99.99% treatment
- All groundwater and soil impacts below Standards
- Successful clean-up



### **Residential Oil Spill Case Study**



## Case Study #3







#### Background:

- Leaking fuel oil UST
- Surgical excavation to remove soil directly around UST
- Pump and treat system operated at the site for >two years
- More aggressive approach requested
- **Initial Conditions for Vertex:**
- 70 cm of free-product at one location
- Free-product present at 7 MW locations
- Up to 7,500,000 µg/L PHCs in groundwater




#### **Staged Remedial Approach:**

- 1. Demolish residential house
- 2. Install concrete caisson wall on either side of property
- 3. Excavate PHC impacted soils to practical limits
- 4. Direct placement of oxidant in excavation
- 5. Installation of horizontal well infrastructure
- 6. ISCO Injections
- 7. Confirmatory Sampling








Direct placement of 1,500 kg oxidant (sodium persulphate) and base activator

VERTEX




Horizontal wells installed in the trenches at the base of the excavation





#### Flowing Sands Case Study



#### Summary:

- "Surgical" removal of impacted soils and pump and treat was ineffective.
- Caissons installed, soils excavated, chemical oxidation (direct placement and injection).
- Approx. 2,000 kg of persulphate and associated base activation used.

#### **Results:**

- Greater than 99.99% treatment obtained.
- All wells below drinking water standards for four consecutive events.
- Successful clean-up (after unsuccessful start).



# Closing



## Conclusions

- Single remediation approach not always the best approach to PHC remediation
- Excavation excellent remedial approach, but:
  - Inaccessible soils can be expensive to remove
    - i.e. property boundary, beneath footings, close to or in bedrock
  - Impacted groundwater can remain after a dig
  - Digging impacted groundwater not cost effective
- ISCO can be applied by direct placement, injection through horizontal wells and/or through temporary injection points
- Stringent GW Standards reached with ISCO



# **Closing Thought**

"You've got to be very careful if you don't know where you are going, because you might not get there"

Yogi Berra



### **Questions?**



#### Thank You for Your Time

Bruce Tunnicliffe Vertex Environmental Inc. www.vertexenvironmental.ca (519) 653-8444 x 304 office (519) 249-9184 mobile brucet@vertexenvironmental.ca

